## CRACKER BARREL #100 ROCKING CHAIR ASSEMBLY INSTRUCTIONS



Thank you for purchasing a quality select hardwood rocking chair. Your chair comes with a rich heritage and will become a treasured family heirloom. If you should have any comments or questions, please call the toll-free number below between 8:00 AM and 4:30 PM CST Monday through Friday. Again, we appreciate your business and hope you get many years of enjoyment from this chair. \*NOTE: All perspective of left and right in these instructions is from the view of facing the rocker, not sitting in it.

NOTICE: The Rocking Chair product that you have purchased requires some assembly. As with all furniture, proper assembly is necessary for the safe and comfortable use of your rocker. The manufacturer cannot be responsible for any damage or injury that results from improper assembly of the chair. Please read and follow these instructions carefully and in sequence. If you have any questions please call The Hinkle Chair Company helpline (800) 251-3025.



Screws/Nails/Buttons A

### **PARTS INCLUDED:**

- 1 Chair Seat (A)
- 1 Chair Back (B)
- 1 Headrest (C)
- 2 Runners (D)
- 2 Back Spindles 19 inches (E)
- 1 Front Spindle 22 inches (F)
- 1 Chair Side left (G-L)
- 1 Chair Side right (G-R)
- 2 Turned Front Spindles (H)

#### Nail pack w/4 nails **4** Seat Screws

Hardware:

10 Buttons **10 Side Screws** 1 Hex Wrench

### TOOLS REQUIRED FOR ASSEMBLY: (NOT INCLUDED)

Rubber Mallet or Hammer with cloth to protect the wood finish Screwdriver (Hand) Electric not recommended.

### \*\*Attention/Stop\*\*



### READ THIS BEFORE ASSEMBLY! FAILURE TO FOLLOW THESE PROCEDURES WILL VOID YOUR WARRANTY!

Hinkle Chair Company has made every effort to provide you with a ready-to-assemble product that has the same quality as our fully assembled rocking chairs. Please follow the instructions below to protect you (The Customer) from accepting responsibility for a product that is damaged or incomplete.

1<sup>st</sup>) Inspect all parts for any imperfection that might have occurred during shipping.

 $2^{nd}$ ) If there is damaged or missing parts please call 800-251-3025. Do not begin assembly until you have all the correct parts.

3<sup>rd</sup>) Follow steps 1 through 3 completely pre-assembling the chair without applying any of the following; Buttons, Screws, or Nails.

4<sup>th</sup>) When you have determined that all parts are available and undamaged, and that all parts and assemblies fit properly, proceed with steps 1 through 3 applying fasteners as indicated in the steps.

This product is intended for a covered porch or indoors. This product should be cleaned weekly as you would with any other wooden furniture product. If at any time during these steps, assistance is needed, please contact The Hinkle Chair Company Customer Service (800) 251-3025 Lay Chair Side Left (G-L) on the holes facing up on the shipping box to protect the finish. Install Front Spindle (F) Turned Spindles (H), and Back Spindles (E) as shown in Figure 1.



### Insert Chair Back (B) into mortises on Chair Side. Note that the bevel faces the rear of the chair. Figure 2.



#### **STEP 1:**

Insert Headrest (C) into the mortise in the Chair Side. Ensure that both the Headrest (C), all Spindles and Chair Back (B) are fully inserted into the mortises. Medallion to the rear. Figure 3

Lay the Chair Seat (A) into the Chair Side (G-L). The seat must be placed as shown in Figure 5 before the next step or the chair will need to be dis-assembled to insert the seat. Figure 4





С



4

#### **STEP 2:**

Lay Chair Side (G-R) over corresponding spindles and components as shown in Figure 6. This step is much easier if two people align the corresponding spindles and components. Once the alignment is complete begin pressing down on the side to fully seat into all of the mortises and holes. A rubber mallet or a hammer with a heavy cloth to protect the finish may be used to tap all components in place. Figure 5.



#### **STEP 2:**

Start at the bottom back post and begin inserting the provided Side screws. With the Hex Wrench that is provided begin to tighten clockwise by turning the wrench. If the screw is not threading into the Spindle or component, remove the Hex Wrench and gently tap with a hammer and repeat the process. Be careful not to over tighten as this will strip out the spindle or component. Once all five are inserted on the right side, carefully flip the chair over on the other side and repeat the entire process. Figure 6.





#### **STEP 3:**

Place Runner (D) onto the tenons at the bottom of the Chair Side. Once the Runner (D) is started onto the tenons gently tap the bottom of the runner until fully seated onto the tenon. Ensure that the pre-drilled holes face to the inside. Repeat for the other side. Figure 7.



#### **STEP 3:**

With the nails that are provided, start with the side that is on the ground, insert the nail into the pre-drilled hole and begin to tap in with a hammer. These should go in fairly easily. Tap in until flush with the side of the runner. Repeat for all four posts. Figure 8.



#### **STEP 3:**

With the Seat Screws provided, thread the screw into the pre-drilled hole and into the bottom of the seat. Hand tighten the screw until it is flush into the spindle and into the pre-drilled counter sink. Repeat for all four screws. Figure 9.





#### **STEP 3:**

With the Buttons provided, gently tap in over the Side Screws that were previously inserted. Ensure that all screws are tight prior to this step. Once the button is placed in the hole, it is very difficult to remove the button without damaging it. Repeat for all 12 Side Screws. Figure 10.

This completes the assembly of this Rocker.



**FIG.10** 

# **CARE TIPS**

# LISTED BELOW ARE SOME TIPS TO HELP KEEP YOUR FURNITURE LOOKING NEW.

To preserve the finish on stained or pure white furniture it is highly recommended that they either be placed indoors or in a protected environment such as a covered porch. In any case the finish will last longer and look better if kept out of direct sunlight and blowing rain. The finish on this furniture will last for a lifetime if used indoors. This furniture is not intended to be used in an unprotected environment. The sun and rain will weather the varnish finish if left out in the elements over time (6 months to one year depending on the climate). Our furniture products need the same attention as any other solid wood furniture and monthly cleaning with any quality household furniture polish will keep your furniture looking new for many years to come. If your climate has high humidity, even if you follow the recommended cleaning intervals above, you may have problems with mold or mildew. To remove the mold and mildew dilute one ounce of bleach into sixteen ounces of water and apply with a soft cloth. More than one application may be necessary. Allow to dry and apply furniture polish to protect the finish.