


## 100 END/SIDE TABLE ASSEMBLY INSTRUCTIONS



**Thank you for purchasing our quality End/Side Table. The product you have purchased requires some assembly. This item has been carefully inspected before packing to ensure it's adherence to our strict Quality Control Standards. Proper assembly will ensure not only your safety, but many years of enjoyable use of this quality product. We STRONGLY suggest that you familiarize yourself with these instructions prior to assembling this product. It's up to you to follow carefully EACH STEP of the assembly process. For your safety, DO NOT SKIP any step indicated in these instructions. Use all the hardware provided as indicated. Be sure to tighten all fasteners securely when instructed to do so. The manufacturer will not be responsible for any damage or injury that results from improper assembly of the table. If you have any questions regarding the assembly of this table, feel free to contact us using the Helpline (800) 251-3025.**

## END/SIDE TABLE ASSEMBLY INSTRUCTIONS



### Parts Included:

- 1- Table Top (A)
- 2- Table Sides (B)
- 4- Side Supports (C)
- 8- Side Support Screws (D)
- 4- Top Screws (E)
- 8- Buttons (F)

### Tools Required For Assembly

Screw Driver and Hammer

## **\*\*Attention/Stop\*\***



### **Please read before assembling this product!**

Our company has made every effort to provide you with a ready-to-assemble product that has the same quality as our fully assembled rocking chairs. In the unlikely event that there are incorrect or missing parts or that parts become damaged during shipping, following the instructions below will protect you (The Customer) from accepting responsibility for a product that is damaged or incomplete.

1<sup>st</sup>) Inspect all parts for any imperfection that might have occurred during shipping.

2<sup>nd</sup>) In the case of damaged parts or incorrect parts, contact the Helpline immediately for a disposition. Instructions will be given or individual parts may be sent as replacements.

3<sup>rd</sup>) When you have determined that all parts are available and undamaged, proceed with steps 1 through 4.

This product is intended for a covered porch or indoors. This product should be cleaned weekly as you would with any other wooden furniture product.

If at any time during these steps, assistance is needed, please contact Customer Service (800) 251-3025

## **STEP 1:**

---

Lay Table Side (B) on the shipping box during assembly to protect it from scratching. Remove Table Side Supports (C) and insert into pre-drilled holes on Table Side (B). Tap the Side Support(C) with hammer.



## **STEP 2:**

---

Repeat for the other side.



### STEP 3:

---

Place other Table Side (B) over the exposed Side Supports (C) and line up into pre-drilled holes. Tap the Table Side (B) with a hammer until the Side Supports (C) are fully seated into the pre-drilled holes. We recommend that you use a rag to protect the finish from the hammer.



### STEP 4:

---

Using the provided Hex Wrench tighten Side Support Screw (D) securely. Repeat for all 8 Side Support Screws (D). Once all Side Support Screws (D) are inserted, place Button (F) into pre-drilled hole. Tap in flush with a hammer.



## **STEP 5:**

---

Lay Table Top (A) on the shipping box. Take assembled sides and place into Table Top (A) as depicted below. Locate pre-drilled holes in Side Support .



## **STEP 2:**

---

Place Top Screws (E) into pre-drilled holes and fully tighten. Repeat for all four corners. You table is now complete. Note: this table should never be used as a step ladder or a stool.



# CARE TIPS

**LISTED BELOW ARE SOME TIPS TO HELP KEEP YOUR FURNITURE LOOKING NEW.**

**To preserve the finish on stained or pure white furniture it is highly recommended that they either be placed indoors or in a protected environment such as a covered porch. In any case the finish will last longer and look better if kept out of direct sunlight and blowing rain. The finish on this furniture will last for a lifetime if used indoors. This furniture is not intended to be used in an unprotected environment. The sun and rain will weather the varnish finish if left out in the elements over time (6 months to one year depending on the climate). Our furniture products need the same attention as any other solid wood furniture and monthly cleaning with any quality household furniture polish will keep your furniture looking new for many years to come. If your climate has high humidity, even if you follow the recommended cleaning intervals above, you may have problems with mold or mildew. To remove the mold and mildew dilute one ounce of bleach into sixteen ounces of water and apply with a soft cloth. More than one application may be necessary. Allow to dry and apply furniture polish to protect the finish.**